

## XT-3815 G2/XT-3915 G2 JUMPER SETTING

Ver. A1

- **JP1 : Select LCD Power**  
Pin 1-2 Short: VCC3  
Pin 2-3 Short: VCC5
- **JP2 : Touch Sound Selection**  
Pin 1-2 Short : for normal USB port  
Pin 2-3 Short : for Resistive Touch Sound used
- **JP3 : COM1/COM2 Pin1 connected Setting**  
Pin 1-3 Short : COM1 Pin1 connected to 12V  
Pin 3-5 Short : COM1 Pin1 connected to DCD  
Pin 2-4 Short : COM2 Pin1 connected to 12V  
Pin 4-6 Short : COM2 Pin1 connected to DCD
- **JP5 : COM3/COM4 Pin1 connected Setting**  
Pin 1-3 Short : COM3 Pin1 connected to 12V  
Pin 3-5 Short : COM3 Pin1 connected to DCD  
Pin 2-4 Short : COM4 Pin1 connected to 12V  
Pin 4-6 Short : COM4 Pin1 connected to DCD
- **JP4 : For CR open/close status port selection**  
Pin 1-3 、 2-4 Short: For COM1  
Pin 3-5 、 4-6 Short : For COM5
- **COM1~COM3 : +5V through BIOS ; VGA +12V through BIOS**  
Press ESC to access Advanced\OEM IO Configuration\  
VGA DSUB 12V : Disabled  
COM1 DB9 5V : Disabled  
COM2 DB9 5V : Disabled  
COM3 DB9 5V : Disabled

• **DIP SWITCH1 (SW1) :**

SWITCH1		FUNCTION
1 On	2 OFF	Normal (Default)
1 OFF	2 ON	Clear CMOS
3	OFF	Reserved

