

## RT-1016A JUMPER SETTING

- **JP1 : COM1/COM2 PORT DC SUPPLY SELECT**
  - Pin 1-3 Short : COM1 Pin1 connected as 12V DC
  - Pin 3-5 Short : COM1 Pin1 connected as No power
  - Pin 2-4 Short : COM2 Pin1 connected as 12V DC
  - Pin 4-6 Short : COM2 Pin1 connected as No power
- **COM1~COM2 : +5V through Android App**
  - Desktop\ COMPWControl
  - COM1 5V : Disabled
  - COM2 5V : Disabled

